

### HOW TO USE THESE DIAGRAMS

The diagram above is a full harness drawing for the Aston Martin Lagonda. The components on this diagram are laid out according to their position on the car for easy location. The component numbers on this diagram correspond with those on the reverse side of this page. The diagram on the reverse side shows the components laid out in numerical order with a definition of their function and a grid number for cross-referring to the above diagram. The second diagram shows precise connection and colour of the cables, and is here explained.

#### COMPONENT CODE & FUNCTION

The component code corresponds with that shown on the harness diagram. It is followed by the precise function of the component and the circuit to which it is related.

#### GRID LOCATION CODE

This alpha-numeric code provides a quick means of cross-reference with the harness diagram.

#### TERMINAL CODES

Terminal Codes with the numbers/letters which are on the actual components.

#### ADDRESS CODE

This code shows the component and terminal (where given) to which the cable is connected, followed by the colour of the cable.


To left hand window "up" relay  
Terminal 87  
coloured brown  
with red tracer

#### GRAPHICAL SYMBOL


The Graphical Symbol consists of an outline representation of the component enclosing a standardised symbol. The standardised symbols are based on those used in DIN Standards.

#### Colour Code

bl = blue	vi = purple
br = brown	ws = white
ge = yellow	rs = pink
gn = green	rt = red
lgn = lightgreen	sw = black
gr = slate	og = orange



USA WIRING BROADSHEET



LAGONDA

1076

ASTON MARTIN LAGONDA LIMITED  
NEWPORT PAGNELL, BUCKINGHAMSHIRE MK169AN ENGLAND

October 1982

